



U/2 RACK™ For Concrete Installations

Installation Layouts and Space Requirements:


Based on recommendations from the Association of Pedestrian and Bicycle Professionals and over 30 years in the bike parking industry, the following diagrams show typical configurations and space allowances for installations of multiple bike racks.

The minimum space between each rack is 3'0", more if possible to allow for ease of access. Aisles separate the rows of racks, with a minimum between aisles to be 4'-6", to allow for one person to walk one bike. In high traffic areas, the recommended aisle width is 6'-0". Aisle widths are measured tip to tip of bike tires between the rows of racks. Six feet should be allowed for each row of parked bicycles. Conventional upright bicycles are just less than 72 inches long, with handlebar widths varying from 22"-27" and can be easily accommodated with these recommended spacings.



NOTE: Not warranted for other surface installations.

Each rack has plastisol rubberized coating or TGIC polyester powder coat to protect bike frame, U-Lock compatible to secure bike and frame




CycleSafe®
SECURE BICYCLE PARKING

888 950 6531 CYCLESAFECOM

INEQ@CYCLESAFE.COM

©2009 Cycle-Safe, Inc.


*Cycle-Safe® and ProPak® are Federally registered trademarks. Printed on recycled paper.



Hardware Kit-G
(Part #12716)



Set Tool (Part #12723)



SURFACE INSTALLATION - U/2 Rack:

Common Tools Needed:

- Hammer Drill Motor
- Impact Wrench or Socket Wrench with 1/2" drive
- 1/2" concrete drill bit
- T-45 Torx Bit (#12721 provided)
- 3/8" Set Tool (#12723 provided)
- 2 LB. Hammer
- Concrete Adhesive
- Tape Measure
- Chalk Line
- Safety Goggles

Step 1: Determine desired placement of all bike racks before drilling any holes; avoiding concrete expansion joints. (Recommended spacing is 3 foot centers.)

Step 2: Using predetermined center lines from step 1, mark 4-hole locations for drilling using rack flange as template.

Step 3: Using the 1/2" drill bit, drill holes in the concrete - 2" deep. Do not damage the rack pipe surface or flange with the hammer drill or drill bit.

Step 4: Clean out the hole using a blow-out bulb, vacuum, or compressed air. Do not use water. It is very important to clean out the hole to ensure correct holding of the anchor.

Step 5: Insert concrete adhesive into the hole. Drop the anchor in the hole. Insert the set tool (Part #12723) into each anchor. Using a hammer, pound the set tool until the shoulder reaches the lip of the anchor. This will assure proper anchor expansion. Let the concrete adhesive cure according to mgf instructions before mounting the U-rack.

Step 6: Place rack over anchors. Place flat washer on security screw and thread into the anchor using the Torx bit (Part #12721 - provided). Wrench until flush with the flange plate.

Step 7: Check the installation to make sure it is tight to the concrete. Dispose of packaging.

Step 8: Fill in the Torx hole on the anchor with concrete adhesive.

RAIL MOUNT INSTALLATION - U/2 Rack:

The CycleSafe Rail-Mount inverted-U modular design can be placed in areas where permanent anchoring is not desired. Simply use the 6 foot C-rail and place racks on top, securing with supplied tamper resistant hardware, 3/8" x 1-1/2" SS screw with washer and clamping nut.

Tools needed: T-45 Torx Bit (12721) or 7/32" hex bit, and a power drill.

IN-GROUND INSTALLATION - U/2 Rack:

Recommended installation methods for in-ground style rack:

If installing on existing concrete, CycleSafe® U/2 Bike Racks can be anchored with a non-shrink grout poured into a 4" or 6" diameter by 12" deep core drilled holes. In-ground installations for new improved surfaces 9" Sonotube forms can be put in place to create 18" footings. U/2 inverted-U racks come in optional square pipe or in two-bend configurations.

This is the standard for new construction and the most secure type of inverted-U installation. Existing concrete surface may be core drilled with a 3"-4" hole saw and filled with quikcrete or a construction adhesive.

For further information contact CYCLESAFE INC.
Customer Service 888-950-6531



888.950.6531 CYCLESAFE.COM INFO@CYCLESAFE.COM

©2009 Cycle-Safe, Inc. *Cycle-Safe® and ProPark® are Federally registered trademarks.

