


RELEASE DATE:	9-Jun-10	BY:	MW
REVISION DATE:	10-Aug-23	REV	G
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		



## ECOPARK LOCKER ASSEMBLY INSTRUCTIONS

**SCOPE:** This installation instruction will describe how to assemble a single tier locker with two sided access and secure it to a solid base.



### Tools Needed

Battery powered drill motor  
 3/16" hex bit (4.5 metric)  
 7/32" hex bit (5.5 metric)  
 1/2" socket or end wrench (#13 metric)  
 9/16" socket or end wrench (#16 metric)  
 Carpenter's square  
 Torpedo level  
 Concrete Epoxy  
 Flat furniture dolly

**Items 6 - 9  
and 12  
Kit # 19550**


Item	Qty	Description	Part #
1	2	Door Frame Assembly	19526
2	2	End Panel Weldment	19524
3	1	Partition (OSB) Panel	10101
4	1	Top Panel	10301
5	2	Door Panel Assembly	varies
6	16	3/8-16NC BHCS x 3/4" LG ZP	19569
7	6	5/16-18 NC whiz locknut ZP	19582
8	10	5/16-18 NC BHCS x 3/4" LG ZP	19581
9	6	5/16-18NC BHCS x 1" LG. ZP	17112
10	6	Drive Pin Lag Kit (std)	19571
11	4	Adj. Leveler kit (option)	19575
12	10	5/16-18NC x 1 1/4" HHMS ZP	10222

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT  
 ALWAYS WEAR SAFETY GLASSES.**

RELEASE DATE:	9-Jun-10	BY:	MW
REVISION DATE:	10-Aug-23	REV	G
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		



## ***ECOPARK LOCKER ASSEMBLY INSTRUCTIONS***




- 1 Align the hinge of the door panel assembly to the door frame assembly nutserts and fasten with 5/16-18NC BHCS X 3/4" screws (19581). There are (5) nutserts located on the door frame assembly. Repeat for the second door.

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT**  
**ALWAYS WEAR SAFETY GLASSES.**

RELEASE DATE:	9-Jun-10	BY:	MW
REVISION DATE:	10-Aug-23	REV	G
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		



## ECOPARK LOCKER ASSEMBLY INSTRUCTIONS




Attach the partition panel (10101) to one of the door and frame assembly using three 5/16-18NC X 1" screws (17112) and three 5/16-18NC whiz lock nuts (19582).

Attach the other door and frame assembly to the opposite end of the partition panel.

5/16-18NC Whiz Nut (19582)  
5/16-18NC X 1" Screw (17112)

**DO NOT TIGHTEN FASTENERS UNTIL THE  
END PANEL WELDMENTS (19524) HAVE BEEN  
ASSEMBLED AND SQUARED**


- 4**
- A)** CAREFULLY position End Panel Weldment (19524) behind Door Frame Assembly flange (19526) at one end.
- B)** At opposite Door Frame CAREFULLY pull the flange outward and rotate the End Panel Weldment behind the Door Frame flange.
- C)** Fasten with 3/8-16NC X 3/4" BHCS (19569)



**4 A)** Insert end panels this direction

**DO NOT SLIDE ON SURFACE**

**4 B)** Door Frame Assembly flange



**4 C)** 3/8-16NC X 3/4" BHCS (19569)  
(4) per end on each panel

**ALWAYS OBSERVE POSTED SAFETY  
GUIDELINES WHEN ASSEMBLING  
THIS PRODUCT. ALWAYS WEAR  
SAFETY GLASSES.**


RELEASE DATE:	9-Jun-10	BY:	MW
REVISION DATE:	10-Aug-23	REV	G
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		




## ECOPARK LOCKER ASSEMBLY INSTRUCTIONS

**MAKE SURE THE FRAME IS SQUARED PRIOR TO FASTENING THE TOP PANEL TO THE FRAME.**

DO NOT overtighten the fasteners to the SMC plastic top panel. They should only be wrench snug!




- 5 Align top panel bosses (10301) with end panel weldment holes (19524).
- 6 Using the 5/16-18NC screws (10222) fasten into the top panel through the end panel weldments holes.



5/16-18NC HHMS X 1 1/4" LG. (10222)

Location of fastening bosses  
(5) places per side



Bottom view of top panel (10301)

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT  
ALWAYS WEAR SAFETY GLASSES.**

RELEASE DATE:	9-Jun-10	BY:	MW
REVISION DATE:	10-Aug-23	REV	G
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		




## ECOPARK LOCKER ASSEMBLY INSTRUCTIONS

Move the completed assembly to the desired location and anchor into the ground.

**Do Not Slide Along Surface when moving locker**

A 6' access lane is recommended around three (3) sides of unit.



1/4" X 1-1/2" Hammer Zinc Alloy Anchor (19572) and 1/4" X 1" Diameter Washer (19577) for insertion into ground surface. Six (6) sets are used: (2) through door frames and (1) per end panel assembly.

Drill and insert the anchors in determined location. Use the concrete epoxy in the anchor holes and allow to set per manufacturer's instructions.

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT  
ALWAYS WEAR SAFETY GLASSES.**