


RELEASE DATE:	9-Jun-10	BY:	G.M.
REVISION DATE:		REV	
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		



## ASSEMBLY INSTRUCTIONS

### SCOPE:

This installation instruction will describe how to assemble a single tier locker with two sided access and secure it to a solid base.



### Tools Needed

Battery powered drill motor  
 #23 star bit (included)  
 7/32" hex wrench  
 1/2" socket or end wrench  
 9/16" socket or end wrench  
 Carpenter's square  
 Torpedo level


ITEM	QTY	DESCRIPTION	MATERIAL
1	2	DOOR FRAME ASSEMBLY	19510
2	2	END PANEL WELDMENT	19516
3	1	DIVIDER PANEL	19520
4	1	TOP PANEL {THIN}	19550
5	2	DOOR PANEL ASSEMBLY	19525
6	28	3/8-16NC BHCS X 3/4" LG.	19521
7	18	3/8-16NC WHIZ LOCK NUT	11105
8	10	5/16-18NC HHMS X 1-1/4" LG.	10222
9	6	3/8"-16NC X 1 7/8" ANCHOR BOLT	10211
10	6	3/8" S5 FLAT WASHER	10909

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT**  
**ALWAYS WEAR SAFETY GLASSES.**

RELEASE DATE:	9-Jun-10	BY:	G.M.
REVISION DATE:		REV	
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		




## ASSEMBLY INSTRUCTIONS




- 1 Attach the divider panel (19520) to one of door frame assembly (19510) using three 3/8-16NC screws (19521) and three 3/8-16NC whiz lock nuts (11105).
- 2 Attach the other door frame assembly (19510) to the opposite end of the divider panel.

**DO NOT TIGHTEN FASTENERS UNTIL THE END PANEL WELDMENTS (19516) HAVE BEEN ASSEMBLED AND SQUARED**



- 3 Slide end panel weldments (19516) into door frame assembly (19510) and fasten with 3/8-16NC screws (19521) and 3/8-16NC whiz lock nuts (11105).

Insert end panels this direction



**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT. ALWAYS WEAR SAFETY GLASSES.**

3/8-16NC whiz nut (11105)  
(4) per end on each panel

3/8-16NC screw (19521)  
(4) per end on each panel


RELEASE DATE:	9-Jun-10	BY:	G.M.
REVISION DATE:		REV	
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		




## **ASSEMBLY INSTRUCTIONS**

**MAKE SURE THE FRAME IS SQUARED PRIOR TO FASTENING THE TOP PANEL TO THE FRAME.**

DO NOT overtighten the fasteners to the SMC plastic top panel. They should only be wrench snug!




- 4 Align top panel bosses (19550) with end panel weldment holes (19516).
- 5 Using the 5/16-18NC screws (10222) fasten into the top panel through the end panel weldments holes.



5/16-18NC HHMS X 1 1/4" LG. (10222)

Location of fastening bosses  
(5) places per side




Bottom view of top panel (19550)

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT  
ALWAYS WEAR SAFETY GLASSES.**

RELEASE DATE:	9-Jun-10	BY:	G.M.
REVISION DATE:		REV	
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		



## **ASSEMBLY INSTRUCTIONS**



The final step to complete the locker is to fasten the door panel assemblies (19525) onto the door frame assemblies (19510).

**MAKE SURE THE DOORS ARE SQUARED BEFORE TIGHTENING THE SCREWS TO THE FRAME**

- 6 Align the hinge of the door panel assembly to the door frame assembly nutserts and fasten with 3/8-16NC screws (19521). There are (5) nutserts located on the door frame assembly.


**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT  
ALWAYS WEAR SAFETY GLASSES.**

RELEASE DATE:	9-Jun-10	BY:	G.M.
REVISION DATE:		REV	
PRODUCT NAME:	EcoPark Locker		
PRODUCT NUMBER:	19500		



## **ASSEMBLY INSTRUCTIONS**

Move the completed assembly to the desired location and anchor into the ground.  
**A 6' access lane is recommended around three (3) sides of unit.**



3/8-16NC Anchor bolt (10211) and washer (10909) for insertion into ground surface.  
Six (6) sets are used: (2) through door frames and (1) per end panel assembly.

Drill and insert the anchors in determined location. Use the concrete epoxy in the anchor holes and allow to set per manufacturer's instructions.

**ALWAYS OBSERVE POSTED SAFETY GUIDELINES WHEN ASSEMBLING THIS PRODUCT  
ALWAYS WEAR SAFETY GLASSES.**